

# ezoBord™

## Installation Guide – Applying Double-sided ezoTape to ezoBord Material

- 1) Identify the two distinct sides of the ezoBord material. Identification of each side is best accomplished by running your hand lightly over the surface of each side.
  - **Front Face:** Smooth-side of the material when applying to a wall/surface.
  - **Back Face:** Fuzzy-side of the material.
- 2) The tape is applied to the Back Side of the ezoBord material.
  - Cover the outside perimeter of the panel. It is important to be approximately 1/8" from the edge of the material – without going over the edge. If it is applied over the edges, it will be visible once mounted.
  - Apply vertical tape strips every 18" – 24" apart, dependent upon the dimensions of the panel, to minimize "sheer" effect.



- 3) Once the tape is placed on the back side of the panel, aggressively burnish the brown protective cover of the tape to actively engage the tape into the fibers of the ezoBord material.
- 4) Remove the protective cover of the tape and apply to the desired location. (This is a very gummy tape, and multiple re-adjustments can compromise its effectiveness.)
- 5) Apply pressure to the entire panel against the substrate to insure a thorough connection.

*\*This is not intended for ceiling/over-head/cloud applications, as a positive connection into the ezoBord panel is recommended.\**